

METHOD STATEMENT

Process :	BACK OF HOUSE FLOOR TREATMENT
Site :	APPLE – R393 CRIBBS CAUSEWAY BRISTOL
Operations Director :	Thomas Campton
Site Supervisor :	Owyn Parrott
Originator :	D.Campton
Position:	Director
Date:	7th February 2018
H & S Representative	
<p>This method statement is critical to the health and safety of the activity it relates to. It is to be strictly adhered to. Any deviation must first be authorised by the Site Supervisor.</p>	
Specified Works :	Floor Treatment Back Office Areas
Access :	As specified
Working Environment and Restrictions : Health & Safety , Security & Fire Regulations In accordance with our policies and site requirements	
Protection of Others :	Work to be undertaken outside trading hours Hazard Warning Signage placed strategically& areas cordoned off.
Emergency Procedures :	Normal site emergency procedures
Personal Protective Equipment	Appropriate footwear. PPE issued - Gloves ,Safety Glasses., Ear plugs, Masks , to be used where appropriate & as instructed.
Plant and Equipment:	Rotary Floor Machines, Wet Vacuums, sundry items
Materials Handling/Storage and Safety Information:	No special procedures required Disposal in accordance with MSDS
Stages: (to be undertaken in correct sequence)	
<p>BACK OF HOUSE AREAS – Strip and Seal</p> <ol style="list-style-type: none"> 1. Make contact with Security and Site contact 2. Check in using Service Channel GPS 3. Cordon off area where work to be carried out & position Warning Signage 4. Sweep / Pre Vacuum all areas. 5. Apply diluted solution of Turbo Strip using mops 6. Agitate using Floor Machine & pad. 7. Use doodle bugs to agitate in corners & edges 8 .Recover Slurry using Wet Vacuums. 9. Rinse thoroughly & allow to dry 10. Apply 2 coats of Secura Floor Sealant at right angles for even coverage- ensuring surface & Applicator free of dust & particles 11. Remove all products & equipment from site 12 . Sign out of Work Order & site <p>N.B. No Foot or wheeled access for 4.6 hours to enable dressing to dry & harden, time will depend on ambient temperature</p>	

